

## Hybrid Illumination Setup

## Summary:

Hybrid illumination cameras are a new line of products that can operate in a few different modes:

1. Color247 Mode (Default Mode)
2. IR Mode
3. Hybrid Mode

Hybrid Mode is defined as utilizing IR in low illumination settings and having the white light turn on when events are triggered.

## Configuration:

As of currently (2023/06/15), the only recorder that can configure through the local interface are the [LTN87XXD-PXX](#) NVRs.

Configuring through the browser will be the most common route for most systems.

1. Access the camera through a browser (plugin is not required). Navigate to Configuration -> Image. Expand the Day/Night switch section. The setting that needs to change is “Supplement Light Mode” from “White Supplement Light” to “Smart”

The screenshot displays the Platinum NVR web interface. The top navigation bar includes 'Live View', 'Playback', 'Picture', and 'Configuration'. The left sidebar shows a menu with 'Image' highlighted. The main content area shows the 'Image Parameters Switch' configuration page. The 'Day/Night Switch' section is expanded, and the 'Supplement Light Mode' dropdown menu is open, showing 'Smart' as the selected option. Red arrows and labels #1 through #4 point to the 'Image' menu item, the 'Configuration' tab, the 'Day/Night Switch' section, and the 'Supplement Light Mode' dropdown menu respectively.